

Shower Tray Installation Instructions

Standard Height Shower Trays:

STQLW 129, STQRW 912, STW 129, STW 128, STW 760,
STQW 800, STW 800, STQW 900, STW 900

IMPORTANT: Please remove protective covers and inspect tray **prior** to installation. Damaged goods cannot be replaced once installed.

CONTENTS:

- | | |
|--------------------|----|
| 1. Shower Tray | x1 |
| 2. Fast flow waste | x1 |

INSTRUCTION

Note: make all plumbing connections & fit the bottom section of the waste before fitting the tray

1. The tray area must stand on a level, rigid base of concrete or marine plywood over the floorboards. The base must allow for the waste to protrude through
2. Place the tray on the level base created in step 1 using a 5:1 cement & sand mix; ensuring the tray hole lines up with the waste outlet
3. Check that the tray is level at all points
4. Fit the remaining waste components as shown, ensuring the waste will not move. Important: do not over tighten screws as gasket may split
5. Check that the waste disposes of the water effectively & that there are no leaks
6. Use silicon to seal the join where the tray touches the wall

AFTERCARE INSTRUCTIONS

Your product has a high quality finish and should be treated with care to preserve the visible surfaces. A damp cloth can be used to wipe the surfaces clean. Any occasional stubborn stains can be removed using warm soapy water.

Take care when using hair colourants and peroxides as these chemicals can damage the surface of your product. All cleaning agents or chemicals should be rinsed off the product immediately after use.

Do not pour any chemical drain cleaner down the waste trap.

GUARANTEE

All products are manufactured to the highest standards and a 5-year guarantee covers any defect in manufacture. Note: this guarantee will only be valid for the initial purchaser. For full details of our guarantee, please refer to the current brochure.

In the interests of continuous product development we reserve the right to alter the specification as necessary.

Please keep these instructions for future reference & request of replacement parts

1.

Marine plywood or concrete base

Plumb waste components before installing tray

Create a level base for the tray to sit on, allowing enough clearance for minor adjustments to the waste position. Make plumbing connections & fit bottom waste components under floorboards.

2.

Apply 5:1 sand/cement mix over whole area

Mix a 5:1 sand/cement ratio to fix the tray, working around the waste.

3.

+/- 0mm

+/- 0mm

Ensure the tray is level at all points.

4.

Install the remaining parts of the waste and ensure the securing ring that is screwed in to the bottom waste isn't over tightened. Use silicone to seal where necessary.

24 h

For further assistance, please contact Bristan: Sales: 0844 701 6271 Customer Services: 0844 701 6275 Email: enquire@bristan.com