

BRISTAN

Echo Sink Mixer

Fitting Instructions & Contents List

Please keep these instructions for future reference and for the ordering of spare parts.

AFTERCARE INSTRUCTIONS

Your fitting has a high quality finish and should be treated with care to preserve the visible surfaces.

All surface finishes will wear if not cleaned correctly, the only safe way to clean your mixer is to wipe with a soft damp cloth. Stains can be removed using washing up liquid. All bath cleaning powders and liquids will damage the surface of your fitting even the non scratch cleaners.

GUARANTEE

All products are manufactured to the highest standards and a 5 year guarantee covers any defect in manufacture.

NOTE: - the 5 year guarantee on the valve is invalidated if damaged by any waterborne debris.

PRODUCT CODE: EC SNK C

TELEPHONE HELP LINE! +44 (0)870 4425553

Bristan Limited
Lagrange
Lichfield Road Industrial Estate
Tamworth
Staffordshire
B79 7XD
UK

Web Site: www.bristan.com
Telephone: +44 (0)870 4425556
Facsimile: +44 (0)870 4425554
Email: enquire@bristan.com
(FI EC SNK) (Rev. D1) (SM)



WATER PRESSURE


This mixer is suitable for use at a minimum supply pressure of 0.3 bar. However for optimum use both the hot and cold supplies should be reasonably balanced.

If the fitting is tank fed, then the minimum distance from the outlet of the nozzle to the underside of the cold tank should be approximately 3.0 metres to ensure adequate performance.

This mixer should be installed in compliance with Water Regulations. For further details contact your Local Water Authority.

CONTENTS

- 1. Mixer Body (x1)
- 2. Threaded Rod (x1)
- 3. Nut (x1)
- 4. Rubber 'C' Washer (x1)
- 5. Metal 'C' Washer (x1)
- 6. Copper Tail Pipes (x2)
- a. Valve (x2)
- b. Handle (x2)
- c. Screw (x2)
- d. Indices (x2)



INSTALLATION

1. Identify all components and check for completeness, particularly before arranging fitting.
2. Fit the mixer body (1) to the sink using the 'C' plate fixing kit. The 'C' shaped rubber (4) and metal (5) washers go on the underside of the sink to be secured by the nut (3) and threaded rod (2).
3. Fit the tail pipes (6) to the fitting and connect the hot and cold supplies.
4. Fully open both valves (a) by turning handles (b), letting them run for a few minutes to check all joints and connections for leaks.
5. See over the page for aftercare instructions.

MAINTENANCE

If the fitting begins to drip:

1. Turn off the water supply.
2. Remove indices (d) and screw (c), then remove handle (b) by pulling from valve (a).
3. Using a suitable spanner, remove valve. Once removed, carefully clean seating, rubber washer and ceramic disc.
4. Replace all of the above then turn on the water supply.
5. If problem persists contact our helpline quoting the product code.

Please Note: -

In the unlikely event you find a part missing please contact our Customer Service Help line on +44 (0)870 4425553 or email enquire@bristan.com for immediate despatch of part.