#### AFTERCARE INSTRUCTIONS

Your fitting has a high quality finish and should be treated with care to preserve the visible surfaces. All surface finishes will wear if not cleaned correctly, the only safe way to clean your mixer is to wipe with a soft damp cloth. Stains can be removed using washing up liquid. All bath cleaning powders and liquids will damage the surface of your fitting even the non scratch cleaners.

### **GUARANTEE**

All products are manufactured to the highest standards and a 5 year guarantee covers any defect in manufacture. As gold and special effect finishes are softer than chromium plate, special care must be taken when cleaning; a 3 year guarantee covers these finishes.

**NOTE:** The 5 year guarantee on the valves is invalidated if damaged by any waterborne debris.

In the interests of continuous product development we reserve the right to alter specification as necessary.

PRODUCT CODE: PM WMBSM C / SAT / ST TELEPHONE HELPLINE: 0844 701 6273

Bristan Group Ltd Birch Coppice Business Park Dordon Tamworth Staffordshire B78 1SG UK

A Masco Company

Web Site: www.bristan.com
Telephone: 0844 701 6273
Facsimile: 0844 701 6275
Email: enquire@bristan.com

(FI PM WMBSM) (D3) (ST)



# Prism Wall Mounted Bath Shower Mixer

# Fitting Instructions & Contents List

Please keep these instructions for future reference and for the ordering of spare parts



#### WATER PRESSURE

This mixer is only suitable for use at mains supply pressures. (Minimum 1.0 bar). For optimum use both the hot and cold supplies should be reasonably balanced. This mixer should be installed in compliance with Water Regulations. Where the supplies are unbalanced, i.e. hot water from the cylinder tank / cold from the mains, approved check valves must be fitted in the supply pipes. For further details contact your Local Water Authority.

# INSTALLATION

- Identify all components and check for completeness, particularly before arranging fitting.
- Fit and seal the elbows (6) into the wall connections, 1/2" BSP female (not provided).
- Fit the flange covers (5) and mixer body to the elbows (6) using the large sealing washers (7) and connect the hot and cold water supplies.
- Fit the hose (9) to the mixer and the handset (10) using the small sealing washers (8).



Prior to drilling into walls, check there are no hidden electrical wires, cables or water supply pipes with the aid of an electronic detector. If you use power tools do not forget to:

- Wear eye protection
- Unplug equipment after use
- 5. Fix wall bracket (15) to the wall, ensuring that the handset (10) will reach it.
- Fully open the mixer in the mid position, letting it run for a few minutes to check all joints for leaks.
- 7. Operate the mixer in both bath and shower mode.
- 8. To switch from bath to shower mode, pull the diverter knob (11) up. After use the mixer automatically reverts to the bath filling mode.
- 9. See over the page for aftercare instructions.

**NOTE:** As there are no backnuts or fixing plates supplied, the bath shower mixer needs to be connected with rigid pipe work. (Wall mount fittings for exposed and concealed pipe work are available in the Bristan Product and Price Guide).

**PLEASE NOTE:** In the unlikely event you find a part missing please contact our Customer Service Help line on 0844 701 6273 or email enquire@bristan.com for immediate dispatch of part.

# MAINTENANCE

# If the fitting begins to drip:

- 1. Turn off the water supply.
- Unscrew head lever (1), loosen grub screw (2) with 2.5mm hexagon key and pull off head (3).
- Remove valve.
- 4. Carefully clean seating, rubber washer and ceramic disc.
- 5. Replace valve and head and turn on the water supply.
- Contact our helpline if problem persists.

#### CONTENTS

1.	Head	(x1)	<ol><li>Handset</li></ol>	(x1)
2.	Shroud	(x1)	11. Diverter Knob	(x1)
3.	Retaining Nut	(x1)	12. Head Lever	(x1)
4.	Cartridge	(x1)	13. Grub Screw	(x1)
5.	Flange Covers	(x2)	14. Rawl Plugs	(x2)
6.	Elbows	(x2)	15. Wall Bracket	(x1)
7.	Large Rubber Washer	(x2)	16. Fixing Screws	
8.	Small Rubber Washers	(x2)	17. Cap	(x1)
9.	Hose (x1)	17	16 15	14
		↓	[	L
				— ≟
	m to 175 m	=	<u> </u>	
		_		
	ا في ا	٧	<b>_</b>	
	[ ]	$\overline{}$		
				1 [
			13 12	l E
	1	/		1 [
	2-	——, ∡  <		10
	3			
	4	<del>=</del>	<b>∕</b> ¹¹	
	6 5	┻, ╒	<b>-</b>	
	\ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \	حلل		<u> </u>
		}		_
			/	<del>\</del> {
	Ì	8	•	
	•	_		
		9——	ጏ	
		_		

