GROHE

45 314 (6")
45 316 (4")

45 620

closed   closed

90°   90°

open   **open**

The built in slip coupling prevents damage to, or loosening of the cartridge.

If the lever is out of position it can be reset by turning it against the end stop in other direction.

1.

2.

3.

4.

95.416.031/ÄM 90 472/02.96