

AFTERCARE INSTRUCTIONS

Your fitting has a high quality finish and should be treated with care to preserve the visible surfaces. All surface finishes will wear if not cleaned correctly, the only safe way to clean your mixer is to wipe with a soft damp cloth. Stains can be removed using washing up liquid. All bath cleaning powders and liquids will damage the surface of your fitting, even the non-scratch cleaners.

GUARANTEE

All products are manufactured to the highest standards and a 5 year guarantee covers any defect in manufacture. As gold and special effect finishes are softer than chromium plate, special care must be taken when cleaning; a 3 year guarantee covers these finishes.

NOTE: The 5 year guarantee on the valves is invalidated if damaged by any waterborne debris.

In the interests of continuous product development we reserve the right to alter specification as necessary.

PRODUCT CODE: BL BAS C / BL BID C
TELEPHONE HELP LINE! 01827 311345

Bristan Group Ltd
Birch Coppice Business Park
Dordon
Tamworth
Staffordshire
B78 1SG
UK
A Masco Company

Web Site: www.bristan.com
Telephone: 0844 701 6273
Facsimile: 0844 701 6275
Email: enquire@bristan.com

BRISTAN

Blade Basin/Bidet Mixer

Fitting Instructions & Contents List

Please keep these instructions for future reference and request of replacement part



(F) BL BAS(BID)

(R3)

(U)

For latest prices and delivery to your door visit MyTub Ltd 0845 303 8383 www.mytub.co.uk

WATER PRESSURE

This mixer is suitable for use at all supply pressures. However for optimum use both the hot and cold supplies should be reasonably balanced. If the fitting is installed at low pressure (tank fed), then the minimum distance from the outlet of the nozzle to the underside of the cold tank should be approximately 2.0 metres to ensure adequate performance. This mixer should be installed in compliance with Water Regulations. Where the supplies are unbalanced, i.e. hot water from the cylinder tank / cold from the mains, approved check valves must be fitted in the supply pipes. For further details contact your Local Water Authority.

INSTALLATION

1. Identify all components and check for completeness, particularly before arranging fitting.
2. Fit the mixer body (1) to the basin/bidet using the rubber O-ring (2) and 'C' plate fixing kit. The rubber O-ring (2) goes between the fitting and the basin/bidet, and the 'C' shaped rubber (3) and metal washers' (4) on the underside of the basin/bidet, to be secured by the nuts (5) and threaded rods (6).
3. Fit the tail pipes (7) to the fitting and connect the hot and cold supplies. DO NOT OVERTIGHTEN. Soft copper tails can be carefully bent and cut to length to meet supply pipes.
4. Fit the pop up waste (11), with the shaped washer (12) below and the flat washer (13) above the basin/bidet. It is recommended that a silicon sealant be applied to both sealing faces of washers. The plug height can be set by, adjusting the pop-up rod (8), operating rod (10) and pop-up link (9), and the screw in the base of the plug. Friction for the waste mechanism can be adjusted using the waste body cap (g).
5. Fully open mixer in mid position letting it run for a few minutes, check all joints and connections for leaks.
6. See over the page for aftercare instructions.

Please Note: In the unlikely event you find a part missing please contact our Customer Service Help line on 0844 701 6273 for immediate dispatch of part.

MAINTENANCE

If the fitting begins to drip:

1. Turn off water supplies.
2. Prise out lever cap (a), loosen grub screw (b) and lift off the handle (c).
3. Unscrew the shroud (d) and brass retaining plate (e) and lift out the cartridge (f) complete with seal.
4. Clean or replace cartridge, clean and grease seal and refit.
Note: *that there are locating pins on the bottom of the cartridge that fit in holes inside the tap, to ensure it is fitted correctly.*
5. Refit the handle and tighten the grub screw. Replace the cap.
6. Contact our helpline if problem persists.

INSTALLATION DIAGRAM

