

AFTERCARE INSTRUCTIONS

Your fitting has a high quality finish and should be treated with care to preserve the visible surfaces.

All surface finishes will wear if not cleaned correctly, the only safe way to clean your fitting is to wipe with a soft damp cloth. Stains can be removed using washing up liquid. All bath cleaning powders and liquids will damage the surface of your fitting even the non-scratch cleaners.

GUARANTEE

All products are manufactured to the highest standards and a 5 year guarantee covers any defect in manufacture.

As gold and special effect finishes are softer than chromium plate, special care must be taken when cleaning, a 3 year guarantee covers these finishes.

NOTE: - the 5 year guarantee is invalidated if damaged by any waterborne debris.

PRODUCT CODE: KIT1 C / ST

TELEPHONE HELP LINE! +44 (0) 870 4425553

Bristan Limited
Birch Coppice Business Park
Dordon
Tamworth
Staffordshire
B78 1SG
UK

Web site: www.bristan.com

Telephone: +44 (0) 870 4425556

Facsimile: +44 (0) 870 4425554

Email: enquire@bristan.com

(FI KIT1 30/04/02 MZ)

BRISTAN

Quadrant Riser Rail Kit

Fitting Instructions



Before starting any installation project, consider "safety" first. Look for the "safety note" sign and read the safety advice.

Please keep these instructions for future reference

CONTENT

- Slider rail (x1)
- Slider (x1)
- Wall bracket assemblies (x2)
- Wall fixing kit (x2)
- Hose (x1)
- Handset (x1)

INSTALLATION

1. Identify all components and check for completeness, particularly before arranging installation.
2. Pulling out the wall bracket securing plugs (1) from ends of riser tube (3) and removing the wall bracket assemblies (2) will reveal the wall-fixing holes.
3. Use the riser tube (3) loosely assembled with the wall brackets as a template to establish the position for the slider rail and mark out the fixing holes or use the diagram as a guide.

Prior to drilling into walls, check there are no hidden electrical wires, cables or water supply pipes with the aid of an electronic detector. If you use power tools do not forget:

- Wear eye protection
- Unplug equipment after use

SAFETY
NOTE!

4. Drill holes to suit, and insert rawl plugs if required.
5. Screw wall brackets to wall using supplied fixing kit. Make sure the holes in the wall bracket assemblies are horizontal, then position riser tube onto brackets and secure with plugs (2).
6. Please ensure that the hose (5) will connect to your valve in the extreme position with the handset (6) fitted in position, using small sealing washers.

7. See over the page for aftercare instructions.

