



AFTERCARE INSTRUCTIONS

Your fitting has a high quality finish and should be treated with care to preserve the visible surfaces. All surface finishes will wear if not cleaned correctly, the only safe way to clean your fitting is to wipe with a soft damp cloth. Stains can be removed using washing up liquid. All bath cleaning powders and liquids will damage the surface of your fitting even the non-scratch

GUARANTEE

All products are manufactured to the highest standards and 5-year guarantee covers any defect in manufacture. As gold and special effect finishes are softer than chromium plate, special care must be taken when cleaning, a 3-year guarantee covers these finishes.

Any part found to be defective during the above guarantee period will be replaced without charge providing that the product has been installed in accordance with our instructions, used as intended and maintained/serviced as recommended.

In the unlikely event that any problems are encountered with this product's performance on installation, you must obtain guidance/authorisation from our Customer Service Department before any remedial action is taken and be able to supply proof and date of purchase.

The guarantee excludes damage caused by accident, misuse or neglect and does not cover the following:

- Those components subject to wear and tear such as 'O' rings and washers etc,
- Damage caused by faulty installation,
- Damage caused by any waterborne debris,
- Damage caused by improper cleaning products,
- Damage caused by the use of non-Bristan parts,
- The product being used for a purpose other than intended.

The company reserves the right, in the event of a claim not covered by the guarantee, to charge the claimant for parts and labour at current rates. This guarantee is given in addition to and does not affect your statutory rights.

In the interests of continuous product development we reserve the right to alter the specification as necessary.

PRODUCT CODE: PM SPJ C

TELEPHONE HELP LINE! +44 (0) 870 4425553

Bristan Limited
Birch Coppice Business Park
Dordon
Tamworth
Staffordshire
B78 1SG
UK

Web site: www.bristan.com
Telephone: +44 (0) 870 4425556
Facsimile: +44 (0) 870 4425554
Email: enquire@bristan.com



Prism Shower Pole with Body Jets

(PM SPJ C)

Fitting Instructions & Contents List



Before starting any installation project, consider "Safety" first. Look for the "safety note" sign and read the safety advice.

Prior to drilling into walls, check there are no hidden electrical wires, cables or water supply pipes with the aid of an electronic detector. If you use power tools do not forget:

- Wear eye protection
- Unplug equipment after use

Please leave these instructions with the user

WATER PRESSURE

This product is suitable for use at pressures of 1 bar or more, up to a maximum of 8 bar. Installation should be in compliance with Water Regulations. For further details contact your Local Water Authority.

INSTALLATION

This product is designed to be used in conjunction with other products, such as the shower valves, blending valves and stopcocks from the Bristan ranges in order to create a system to suit your requirements.

COMPONENTS

1. Rigid riser (x1)(with integral body jets)
2. Inlet tail (x1)
3. Wall bracket (x1)
4. Fixing screw (x1)
- 5/6 Grub screws (x2)
7. Rose, swivel and washer (x1 of each)
8. Sliding bracket (x1)
 - Handset (x1)
 - Hose (x1)
 - Small sealing washer (x2)

INSTALLATION

This product should be arranged in your system with a supply of mixed water.

1. Identify all components and check for completeness, particularly before arranging fitting.
2. Establish desired position for rigid riser (1) and mark out wall, either by using the assembly as a template or by measuring the product.
3. The lower fixing / 1/2" male inlet tail (2) should be supported and fed by rigid pipe work through the recommended 1/2" female BSP connection (not supplied). Use a thread-sealing compound where necessary.
4. The upper wall bracket support (3) should be fixed to wall using the wall plug and screw (4) supplied.
5. The riser can then be offered into position and secured by the grub screws (5 & 6).

6. Attach rose and swivel (7) to the riser arm using the washer supplied. Connect handset to the diverter outlet (a) using the hose and small sealing washers supplied. The conical end of the hose is used to park the handset in the sliding bracket (8), the height of which can be adjusted by loosening the small lever.

NOTE: - Turn on water supplies to check both correct system function and for leaking from joints/ connections.

7. Flow is diverted between the rose, handset and body jets by simply turning the diverter lever (b).
8. See over the page for aftercare instructions.

MAINTENANCE

The rose, handset and body jets all feature rub clean faceplates for easy removal of scale build up.

