

Open-close rotary actuator with emergency control function for 2- and 3-way ball valves

- · Torque 2 Nm
- · Nominal voltage AC 100 ... 240 V
- · Control: Open-close



A		- 4	4
Overv	/iew	OT	types

Туре	Direction of rotation
TRF230	Deenergised NC, ball valve closed (A – AB = 0%)
TRF230-O	Deenergised NO, ball valve open (A – AB = 100%)

#### **Technical data**

#### Electrical data

Nominal voltage		AC 100 240 V, 50/60 Hz					
Nominal voltage range		AC 85 265 V					
Power consumption	Spring-return Holding position For wire sizing	2.5 W @ nominal torque 1.5 W 5 VA					
Connection		Cable 1 m, 2 x 0.75 mm <sup>2</sup>					
Parallel connection		Yes (note performance data for supply!)					
Torque (nominal torc	ue) Motor Spring-return	Min. 2 Nm @ nominal voltage Min. 2 Nm					
Direction of rotation		see «Overview of types»					
Manual override		No					
Angle of rotation		Max. 95°					

#### **Functional data**

Running time Motor	<75 s (0 2 Nm)					
Spring-return	75 s					
Sound power level Motor	Max. 50 dB (A)					
Spring-return	~43 dB (A)					
Service life	Min. 60'000 emergency settings					
Position indication	Mechanical					
Protection class	II Totally insulated □					
Degree of protection	IP42 in any mounting position					
EMC	CE according to 2004/108/EC					
Low-voltage directive	CE according to 2006/95/EC					
Mode of operation	Type 1 (EN 60730-1)					
Rated impulse voltage	4 kV (EN 60730-1)					
Control pollution degree	3 (EN 60730-1)					
Ambient temperature	−30 +50°C					
Media temperature	+5 +100°C (in ball valve)					
Non-operating temperature	−40 +80°C					
Ambient humidity	95% r.H., non-condensating (EN 60730-1)					
Maintenance	Maintenance-free					
Dimensions	See «Dimensions» on page 2					
Weight	Approx. 600 g (without ball valve)					
Media temperature Non-operating temperature Ambient humidity Maintenance Dimensions	+5 +100°C (in ball valve)  -40 +80°C  95% r.H., non-condensating (EN 60730-1)  Maintenance-free  See «Dimensions» on page 2					

## Safety

#### Dimensions / Weight

## Safety notes



- The actuator has been designed for use in stationary heating, ventilation and air conditioning systems and is not allowed to be used outside the specified field of application, especially in aircraft or in any other airborne means of transport.
- Caution: Power supply voltage!
- It may only be installed by suitably trained personnel. Any legal regulations or regulations issued by authorities must be observed during assembly.
- The device may only be opened at the manufacturer's site. It does not contain any parts that can be replaced or repaired by the user.
- · The cable must not be removed from the device.
- The device contains electrical and electronic components and is not allowed to be disposed
  of as household refuse. All locally valid regulations and requirements must be observed.

# Rotary actuator with emergency control function, AC 230 V, 2 Nm $\,$



## **Product features**

Mode of operation The actuator moves the ball valve to the operating position at the same time as tensioning the

return spring. The ball valve is turned back to the safety position by spring force if the supply

voltage is interrupted.

Simple direct mounting Straightforward direct mounting on the ball valve with only one screw. The mounting position in

High functional reliability The actuator is overload-proof, requires no limit switches and automatically stops when the end

stop is reached.

Combination valve/actuators Refer to the valve documentation for suitable valves, their permitted media temperatures and

closing pressures.


## **Electrical installation**

#### Wiring diagram

## Note


Caution: Power supply voltage!


• Other actuators can be connected in parallel. Note performance data for supply.



# Dimensions [mm]

#### **Dimensional drawings**







**Further documentations** 

- · Complete overview «The complete range of water solutions»
- · Data sheets for ball valves
- · Installation instructions for actuators resp. ball valves
- Notes for project planning (hydraulic characteristic curves and circuits, installation regulations, commissioning, maintenance etc.)









	$\rightarrow$	DN		Rp	G	PN	mm						
										TRFDS(-O)(-T)		TRFS(-O)(-T)	
		mm	"	"	"		L	Н	М	Х	Υ	Χ	Υ
R2K	R3K	10	3/8	3/8			52	35	28	180	80		
R4K	R5K	10	3/8		3/4		69	31.5	34	180	80		
R2	R3	15	1/2	1/2			67	45	39			190	80
R4	R5	15	1/2		1		74	44	38			190	80
R6R	R7R	15	1/2			6	101.5	45	73			190	80

